PEGASI

006 ASSEMBLY INSTRUCTION

Item	Description	Qty
1	Net	1
2	Rim	1
3	Backboard	1
4	Plastic expansion bolt M8X90	4
	PARTS PICTURES	
1-000	2 3 4	

INSTALLATION

Install the backboard (3) and rim(2) on the wall by 4pcs plastic expansion bolts M8X90 (5) as shown.







