



## F181 MANUAL


### PART LIST




1. Net  
1 piece




2. bent tube  
4 pieces



3. Straight tube  
2 pieces



4. Left Rotational  
component  
1 piece



5. Right Rotational  
component  
1 piece

### ASSEMBLY

